





Notes:

1) Pulse count should be 49440.

2) The speedometer and speed sensor do not share a power and ground circuit.







CHARGING SYSTEM

Charge battery to a minimum of 12.8 volts. Load test the battery and replace if necessary. Check battery cables and all connections. Check for current drain or draw with power OFF. Less than 1.4 mA carbureted, and 2.4 mA EFI.

TEST A
Start engine. Measure voltage across the battery terminals.
Is voltage below 13.8 volts or above 14.8 volts?

Above 14.8

Replace voltage regulator. Retest.
06018

Ref. Test A

Below 13.8

Stop engine. test circuit breaker. Measure voltage at both CB terminals.
Is there a voltage difference?

No

Push the reset button on breaker. Replace CB if it cannot be reset.
06052

Ref. Test A

Check for voltage regulator ground. Measure resistance from VR case to battery ground, and also to engine ground.
Is resistance more than 0.5 Ohms?

Yes

Remove VR. Clean and inspect all contact points. Reinstall and retest.
06018

Ref. Test A

No

Remove stator plug, start engine and measure AC voltage across pins.
Is stator output 16 to 20 volts per 1000 RPMs?

Yes

Replace voltage regulator. Retest.
06018

Ref. Test A

No

With engine OFF measure resistance across stator pins.
Is resistance more than 0.5 Ohms?

Yes

Replace stator/rotor. Retest.
06017

Ref. Test A

No

With engine OFF, measure resistance from stator pin to engine ground.
Is continuity present?

No


Reconnect the two-pin stator plug and retest stator/rotor. If low voltage condition still exists, replace stator/rotor. Retest.
06017

Ref. Test A

Yes

VOLTAGE REGULATOR TEST

Note:
1) For diagnosis times above 0.3 call Tech Support.



**STARTING SYSTEM
(ENGINE WILL NOT CRANK)**

Charge battery.
Check battery voltage.

Yes

No

TEST B
Attempt to start motorcycle.
Does solenoid engage or attempt to engage?

Inspect charging system.
Refer to **CHARGING SYSTEM** flow chart.

Yes

No

Refer to Test C

No

Does headlight turn off when starter is activated?

Yes

Refer to **STARTER BUTTON** flow chart.

Disconnect green wire from starter solenoid. Measure voltage from solenoid wire to ground when the starter is activated (It is common to have around 8 volts on the wire before the starter is activated).
Does the green wire have battery voltage?

Yes

No

Refer to **STARTER SOLENOID** flow chart.

TEST C
Disable ignition so motorcycle will not start. Measure DC voltage drop from starter housing to negative battery terminal while cranking.
Is the voltage drop greater than 1.0 volts?

Disable ignition so motorcycle will not start. Measure DC voltage drop across power cable from positive battery terminal to starter terminal while cranking.
Is the voltage drop greater than 1.0 volts?

No

No

Yes

Yes

Verify there are no mechanical faults in the engine or drive train. Inspect starter motor. Repair/replace as needed.

Inspect power cable and connections. Clean and repair as needed.

Inspect battery cables and connections. Verify the starter ground/mounting bolt is clean and tight. Clean and repair as needed.

15001

06004


06004

Ref. Test B

Ref. Test B

Note:

1) For diagnosis times above 0.3 call Tech Support.




Section A

**NO START,
ENGINE CRANKS
(2005 – 2008)**

Note:

1) Refer to BDM Service Manual for location of the LEDs for the ignition fault circuit.




Section B

NO START, ENGINE CRANKS (2005 – 2008)

Note:

1) Use appropriate test connector with leads from RK-03 Pigtail Kit located in the Electrical Service Kit #SK-4000-03.




Section C

**NO START,
ENGINE CRANKS
(2005 – 2008)**

Note:

1) Use appropriate test connector with leads from RK-03 Pigtail Kit located in the Electrical Service Kit #SK-4000-03.




Section D

NO START,
ENGINE CRANKS
(2005 – 2008)

Note:

1) Use appropriate test connector with leads from RK-03 Pigtail Kit located in the Electrical Service Kit #SK-4000-03.




Section E

**NO START,
ENGINE CRANKS
(2005 – 2008)**

Note:

1) Use appropriate test connector with leads from RK-03 Pigtail Kit located in the Electrical Service Kit #SK-4000-03.




Section F

NO START, ENGINE CRANKS (2005 – 2008)


Note:

1) Use appropriate test connector with leads from RK-03 Pigtail Kit located in the Electrical Service Kit #SK-4000-03.



Section G


NO START,
ENGINE CRANKS
(2005 – 2008)



Notes:

1) Always recheck oil pressure after any/all repairs.


2) Include an ignition module download with all engine claims.



Notes:


1) Always recheck oil pressure after any/all repairs.

2) Include an ignition module download with all engine claims.




Notes:


1) Include an ignition module download with all engine claims.



Notes:

- 1) Include an ignition module download with all engine claims.







Notes:


1) On 2005 models built before July 8, 2005 inspect primary adjustment shoe, per SB-1059

2) Inspect carrier bearing basket for cracks on all 2005 models.






TRANSMISSION AND PRIMARY LEAKS




Notes:

1) Include an ignition module download with all engine claims.



Note:

1) Allowable leak down is 10psi in a 24 hour period, or 15psi over 200 miles.



**AIR RIDE
COMPRESSOR/RELIEF VALVE
INOPERATIVE**

Remove seat.
Turn key to ON.
Press Start.
Observe The LEDS
on the EHC.

Is the air ride
mode LED On?

Yes

No

Refer to
Test D

Press the Hi or Lo
button and observe
the EHC.

Does the air compressor
or air relief valve LED
illuminate when
pressing the buttons?

No

Yes

These LEDs indicate a fault.
Inspect blue wire (A2) from the
harness and the orange wire
from the compressor.
Inspect pins in the connector;
make sure they are fully seated
and are properly crimped.
Inspect the blue and black wires
(A18 and A32) from the relief valve
for loose connections and for a
short to ground.

Repair wire
as needed.

06006

TEST D

Cycle key.
Press Run to start motorcycle.
Cycle the Hi/Lo button.

Does the headlight go
from hi to low?

No

Replace PCB Boards.
Prior to replacement check
all connections and wiring
from the EHC.

06008
06009


Yes

Call Tech
Support.

MANIFOLD ABSOLUTE PRESSURE (MAP) BAROMETRIC SENSOR ERROR

Note:


1) Always clear historic DTCs before retesting.



INTAKE AIR TEMPERATURE (IAT) SENSOR ERROR

Note:


1) Always clear historic DTCs before retesting.



**FRONT/REAR INJECTOR
OPEN OR SHORT CIRCUIT**

Note:


1) Always clear historic DTCs before retesting.



ENGINE TEMPERATURE SENSOR (ETS) ERROR


Note:

1) Always clear historic DTCs before retesting.



Note:


1) Always clear historic DTCs before retesting.



THROTTLE POSITION SENSOR (TPS) ERROR


Note:

1) Always clear historic DTCs before retesting.



Note:


1) Always clear historic DTCs before retesting.





STEPPER MOTOR ERROR

Note:

1) Always clear historic DTCs before retesting.






**STUCK O₂ SENSOR ERROR
(FRONT OR REAR)**


Note:

1) Always clear historic DTCs before retesting.




Note:

1) Always clear historic DTCs before retesting.




Note:

1) Always clear historic DTCs before retesting.



Note:


1) Always clear historic DTCs before retesting.



BAD SITES (FRONT OR REAR)

Note:

1) Always clear historic DTCs before retesting.



**BAD SITES
(FRONT OR REAR)
(continued)**

Note:

1) Always clear historic DTCs before retesting.

Continued from previous page.

Using ProTune II BDM, read the rear/front cylinder adaptive maps.

Positive values

Negative values

Test affected injector using Pro Tune II BDM test outputs, while monitoring fuel pressure. Compare front and rear pressure drops while injectors are actuated.

Perform a flow test on the affected fuel injector. Ensure that fuel flow stops crisply when the injector is closed. If fuel continues to dribble out of the injector, replace the injector.

No pressure drop

Pressure drops equally

Using the Test Outputs function in Pro Tune II BDM, test the stepper motor. Ensure that the pintle moves freely in the bore. If it does not move freely, remove the stepper motor and clean both the pintle and the bore. Replace the stepper motor if cleaning does not return the stepper to proper operation.

Replace injector that has lower or no pressure drop.
16001

Other mechanical issues may be restricting fuel flow into the engine. Check items which affect intake valve actuation, such as camshaft timing or pushrod adjustment.