

Section F

NO START, ENGINE CRANKS (2005 – 2007)

Note:

1) Use appropriate test connector with leads from RK-03 Pigtail Kit located in the Electrical Service Kit #SK-4000-03.

